

PRODUCT-DETAILS

2520-214

2520-214 Rocker Switch/push button Single rocker alpine white - Reflex SI



Informations générales

Extension du type de produit	2520-214
Code de produit	2CKA001731A0926
EAN	4011395113103
Description courte	2520-214 Rocker Switch/push button Single rocker alpine white - Reflex SI
Description longue	As cover for flush-mounted switch 1gang,2way, intermediate switch, pull switch and push switch.

Installation

Instructions et manuels	No document needed
-------------------------	--------------------

Technique

Fiche produit, informations techniques	No document needed
Application	Switch/push button
Design Range	Reflex SI Reflex SI Linear Reflex SI/SI Linear
Type de montage	Flush Mounted
Type of Fastening	Clamp
Finition de surface	Untreated Glossy
Matériau	Thermoplastic

Model Number	Single rocker
RAL Number	RAL 9010 - Blanc pur
Couleur	alpine white

Environnement

Indice de protection	IP20
Statut RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Informations RoHS	2CKA200000E1596
REACH Declaration	2CKA309999E9999

Dimensions

Produit Largeur Net	54 mm
Produit Hauteur Net	54 mm
Produit Longueur Net	20 mm
Poids net	20 g

Commande

Quantité minimum	1 pièce
Emballage Niveau 1 Unités	carton 10 pièce
Emballage Niveau 1 Poids	0.248 kg
Code douanier	85389099
Pays d'origine	Germany (DE)

Certificats et Déclarations (Numéro de document)

Déclaration de Conformité - CE	2CKA200000E1596
--------------------------------	-----------------

Classifications

ETIM 8	EC000011 - Control element/cover plate for domestic switching devices
ETIM 9	EC000011 - Control element/cover plate for domestic switching devices
Catégorie DEEE	Product Not in WEEE Scope
CN8	8538 90 99
eClass	V11.0 : 27144002

Accessories

Identifiant	Description	Type	Quantity	Unit Of Measure
2CKA001012A2131	2000/1 US-507 Flush Mounted Inserts Rocker/button 1 rocker Off switch 1-pole	2000/1 US-507	1	piece
2CKA001022A0656	2000/2 UK Switch insert Rocker/button 1 rocker 2-pole switch with Neon lamp	2000/2 UK	1	piece
2CKA001012A2193	2000/2 US-101-500 Flush Mounted Inserts Rocker/button 1 rocker 2-pole switch	2000/2 US-101-500	1	piece
2CKA001012A2196	2000/2 US-500 Flush Mounted Inserts Rocker/button 1 rocker 2-pole switch	2000/2 US-500	1	piece
2CKA001011A0816	2000/3 US Switch insert Rocker/button 1 rocker 3-pole switch	2000/3 US	1	piece
2CKA001012A2198	2000/6 US-500 Flush Mounted Inserts Rocker/button 1 rocker Two-way switch	2000/6 US-500	1	piece
2CKA001012A2110	2000/6 US-507 Flush Mounted Inserts Rocker/button 1 rocker Two-way switch	2000/6 US-507	1	piece

2CKA001012A2194	2000/6 USGL-500 Flush Mounted Inserts Rocker/button 1 rocker Two-way switch with Neon lamp	2000/6 USGL-500	1	piece
2CKA001022A0659	2000/6 USK-500 Flush Mounted Inserts Rocker/button 1 rocker Two-way switch with Neon lamp	2000/6 USK-500	1	piece
2CKA001012A0954	2000/6/2 US Switch insert Rocker/button 2 rocker Two-way switch	2000/6/2 US	1	piece
2CKA001012A2199	2000/7 US-500 Flush Mounted Inserts Rocker/button 1 rocker Intermediate switch	2000/7 US-500	1	piece
2CKA001012A2130	2000/7 US-507 Flush Mounted Inserts Rocker/button 1 rocker Intermediate switch	2000/7 US-507	1	piece
2CKA001413A0483	2020 US-201 Switch insert Push button 1 gang 1 rocker Single push button 1 NO 0 NC	2020 US-201	1	piece
2CKA001413A0491	2020 US-205 Switch insert Push button 2 gang 2 rocker Series push button 2 NO 0 NC	2020 US-205	1	piece
2CKA001413A1105	2020 US-205-500 Flush Mounted Inserts Rocker 2 gang 2 rocker Series push button	2020 US-205-500	1	piece
2CKA001413A1104	2020 US-206-500 Flush Mounted Inserts Rocker Single push button	2020 US-206-500	1	piece
2CKA001413A0574	2020 US-500 Flush Mounted Inserts Rocker Single push button	2020 US-500	1	piece
2CKA001413A1078	2020 US-507 Flush Mounted Inserts Rocker 1 rocker Single push button	2020 US-507	1	piece
2CKA001413A1109	2020 USGL-103 Flush Mounted Inserts Pull cord 1 rocker Single push button with Neon lamp	2020 USGL-103	1	piece
2CKA001413A1106	2020 USGL-500 Flush Mounted Inserts Rocker Single push button with Neon lamp	2020 USGL-500	1	piece
2CKA001413A1107	2031 UP-500 Flush Mounted Inserts Rocker 1 rocker Single push button	2031 UP-500	1	piece
2CKA001012A2238	2400/5 USK-500 Flush Mounted Inserts Rocker/button 2 rocker Series switch with LED not exchangeable	2400/5 USK-500	1	piece
2CKA001012A2232	2400/6 US-500 Flush Mounted Inserts Rocker/button 1 rocker Two-way switch	2400/6 US-500	1	piece
2CKA001754A4496	1721 NS-214-500 Cover Frame 1gang(s) alpine white - Reflex SI	1721 NS-214-500	1	piece
2CKA001754A4497	1721 NSKA-214-500 Cover Frame 1gang(s) alpine white - Reflex SI Linear	1721 NSKA-214-500	1	piece
2CKA001754A2163	1722 NS-214 Cover Frame 2gang(s) alpine white - Reflex SI	1722 NS-214	1	piece
2CKA001754A4059	1722 NSKA-214 Cover Frame 2gang(s) alpine white - Reflex SI Linear	1722 NSKA-214	1	piece
2CKA001754A3724	1723 NS-214 Cover Frame 3gang(s) alpine white - Reflex SI	1723 NS-214	1	piece
2CKA001754A4061	1723 NSKA-214 Cover Frame 3gang(s) alpine white - Reflex SI Linear	1723 NSKA-214	1	piece
2CKA001754A4063	1724 NSKA-214 Cover Frame 4gang(s) alpine white - Reflex SI Linear	1724 NSKA-214	1	piece
2CKA001754A2171	1732 NS-214 Cover Frame 2gang(s) alpine white - Reflex SI	1732 NS-214	1	piece
2CKA001754A4060	1732 NSKA-214 Cover Frame 2gang(s) alpine white - Reflex SI Linear	1732 NSKA-214	1	piece
2CKA001754A3732	1733 NS-214 Cover Frame 3gang(s) alpine white - Reflex SI	1733 NS-214	1	piece
2CKA001754A4062	1733 NSKA-214 Cover Frame 3gang(s) alpine white - Reflex SI Linear	1733 NSKA-214	1	piece
2CKA001754A4064	1734 NSKA-214 Cover Frame 4gang(s) alpine white - Reflex SI Linear	1734 NSKA-214	1	piece
2CKA001725A1009	2511 JH-214 Cover Frame 1gang(s) alpine white - Reflex SI	2511 JH-214	1	piece
2CKA001725A1536	2511-214-500 Cover Frame 1gang(s) alpine white - Reflex SI	2511-214-500	1	piece
2CKA001725A1464	2511-214-507 Cover Frame 1gang(s) alpine white - Reflex SI	2511-214-507	1	piece
2CKA001725A1539	2511-214K-102-500 Cover Frame 1gang(s) alpine white - Reflex SI Linear	2511-214K-102-500	1	piece
2CKA001725A1537	2512-214-500 Cover Frame 2gang(s) alpine white - Reflex SI	2512-214-500	1	piece

2CKA001725A1466	2512-214-507 Cover Frame 2gang(s) alpine white - Reflex SI	2512-214-507	1	piece
2CKA001725A1540	2512-214K-102-500 Cover Frame 2gang(s) alpine white - Reflex SI Linear	2512-214K-102-500	1	piece
2CKA001725A1538	2513-214-500 Cover Frame 3gang(s) alpine white - Reflex SI	2513-214-500	1	piece
2CKA001725A1541	2513-214K-102-500 Cover Frame 3gang(s) alpine white - Reflex SI Linear	2513-214K-102-500	1	piece
2CKA001725A1543	2514-214-500 Cover Frame 4gang(s) alpine white - Reflex SI	2514-214-500	1	piece
2CKA001725A1497	2514-214K-102 Cover Frame 4gang(s) alpine white - Reflex SI Linear	2514-214K-102	1	piece
2CKA001725A0969	2515-214 Cover Frame 5gang(s) alpine white - Reflex SI	2515-214	1	piece
2CKA001725A1498	2515-214K-102 Cover Frame 5gang(s) alpine white - Reflex SI Linear	2515-214K-102	1	piece
2CKA001719A0061	2518-214 Cover Frame 1gang(s) alpine white - Reflex SI	2518-214	1	piece
2CKA001714A0229	2145 KI Symbol Symbol "bell" transparent	2145 KI	1	piece
2CKA001714A0211	2145 LI Symbol Symbol "light" transparent	2145 LI	1	piece
2CKA001714A0203	2145 N Symbol transparent	2145 N	1	piece
2CKA001714A0237	2145 TR Symbol Symbol "Key" transparent	2145 TR	1	piece
2CKA001433A0432	2525 KI Symbol Symbol "bell" white - Busch-Duro 2000	2525 KI	1	piece
2CKA001714A0300	2525 KI-10 Cover Plates (partly incl. Insert) Symbols Symbol "bell" white	2525 KI-10	1	piece
2CKA001433A0036	2525 KI-214 Symbol Symbol "bell" alpine white - Busch-balance SI	2525 KI-214	1	piece
2CKA001433A0424	2525 LI Symbol Symbol "light" white - Busch-Duro 2000	2525 LI	1	piece
2CKA001714A0299	2525 LI-10 Cover Plates (partly incl. Insert) Symbols Symbol "light" white	2525 LI-10	1	piece
2CKA001433A0028	2525 LI-214 Symbol Symbol "light" alpine white - Busch-balance SI	2525 LI-214	1	piece
2CKA001433A0416	2525 N Symbol white - Busch-Duro 2000	2525 N	1	piece
2CKA001433A0010	2525 N-214 Symbol alpine white - Busch-balance SI	2525 N-214	1	piece
2CKA001433A0440	2525 TR Symbol Symbol "key/door" white - Busch-Duro 2000	2525 TR	1	piece
2CKA001433A0044	2525 TR-214 Symbol Symbol "key/door" alpine white - Busch-balance SI	2525 TR-214	1	piece
2CKA001433A0457	2525-12 Symbol red - Busch-balance SI	2525-12	1	piece
2CKA001433A0838	2525-13 Symbol Without imprint green - Busch-balance SI	2525-13	1	piece

Catégories

Produits basse tension → Wiring Accessories - Light Switch Ranges → Cover Plates (partly incl. Insert) → Mechanical Controls

