

**DIN 4844**




Vor Wartung oder Reparatur freischalten/  
power off before maintenance or repair

# INSTRUCTION

Aufnahmering für Toledo Flatliner

CE



982386.002	D 162, H 9,5	47 g
982387.002	D 204, H 9,5	62 g
982388.002	D 270, H 9,5	90 g
982389.002	D 331, H 9,5	130 g

