

PRODUCT-DETAILS

# 1734 KA-22G

## 1734 KA-22G Cover Frame 4gang(s) ivory - alpha exclusive



### Informations générales

Extension du type de produit	1734 KA-22G
Code de produit	2CKA001754A4152
EAN	4011395012345
Description courte	1734 KA-22G Cover Frame 4gang(s) ivory - alpha exclusive
Description longue	Vertical.

### Installation

Instructions et manuels	No document needed
-------------------------	--------------------

### Technique

Fiche produit, informations techniques	No document needed
Number of Gangs	4
Design Range	alpha exclusive alpha
Type de montage	Flush Mounted
Type of Fastening	Clamp
Sens de montage	Vertical
Finition de surface	Untreated Glossy
Matériau	Thermoplastic
Label Space Provided	No

RAL Number	RAL 1013 - Blanc perlé
Couleur	ivory

## Environnement

Indice de protection	IP20
Statut RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Informations RoHS	2CKA200000E2610
REACH Declaration	2CKA309999E9999

## Dimensions

Produit Largeur Net	294 mm
Produit Hauteur Net	81 mm
Produit Longueur Net	11 mm
Poids net	52 g

## Commande

Quantité minimum	1 pièce
Emballage Niveau 1 Unités	carton 1 pièce
Emballage Niveau 1 Poids	0.085 kg
Code douanier	85389099
Pays d'origine	Germany (DE)

## Certificats et Déclarations (Numéro de document)

Déclaration de Conformité - CE	2CKA200000E2610
--------------------------------	-----------------

## Classifications

ETIM 8	EC000007 - Cover frame for domestic switching devices
ETIM 9	EC000007 - Cover frame for domestic switching devices
Catégorie DEEE	Product Not in WEEE Scope
CN8	8538 90 99
eClass	V11.0 : 27144001

## Accessories

Identifiant	Description	Type	Quantity	Unit Of Measure
2CKA001731A1931	1716-22 Cover Busch-Infolicht® ivory - alpha	1716-22	1	piece
2CKA001710A2330	1740 DR-22G Cover Plate Venetian blind Turn button Symbol "arrows" and "0" ivory - alpha	1740 DR-22G	1	piece
2CKA001710A3032	1740 DRL-22G Cover Plates (partly incl. Insert) Level switch Turn button Symbol "2-1-3" ivory - alpha	1740 DRL-22G	1	piece
2CKA001710A2389	1742-22G Cover Plate Blind cap 0 gang with Mounting plate ivory - alpha	1742-22G	1	piece
2CKA001724A2727	1743-01-22-500 Cover Plates (partly incl. Insert) SAT 1 gang ivory - alpha	1743-01-22-500	1	piece
2CKA001724A2463	1743-03-22G Cover Plate TV / Radio / SAT 3 gang ivory - alpha	1743-03-22G	1	piece
2CKA001710A2454	1743-22G Cover Plate SAT 2 gang ivory - alpha	1743-22G	1	piece
2CKA001710A2652	1746/10-22G Cover Plate Telecommunication inserts 50 x 50 mm ivory - alpha	1746/10-22G	1	piece

2CKA001710A2488	1746-22G FN Cover Plate Telecommunication inserts 1 gang ivory - alpha	1746-22G FN	1	piece
2CKA001710A2470	1746-22G-101 Cover Plate Telecommunication inserts 50 x 50 mm 1 gang ivory - alpha	1746-22G-101	1	piece
2CKA001710A2546	1748-22G Cover Plate Data connection 2 gang ivory - alpha	1748-22G	1	piece
2CKA001710A2561	1749-22G Cover Plate Cable outlet ivory - alpha	1749-22G	1	piece
2CKA001723A0238	1751-22G Cover Plate Loudspeaker 2 gang ivory - alpha	1751-22G	1	piece
2CKA001710A2348	1755 PZ-22G-101 Cover plate with legend Venetian blind Key Symbol "arrows" ivory - alpha	1755 PZ-22G-101	1	piece
2CKA001710A2355	1755 SLPZ-22G-101 Cover plate with legend Venetian blind Key Characters 0 and 1 ivory - alpha	1755 SLPZ-22G-101	1	piece
2CKA001710A2413	1756-22G Cover Plate Busch-Infolicht® ivory - alpha	1756-22G	1	piece
2CKA001724A2513	1758-22G Cover plate with labelling field For data connection housing 2 gang ivory - alpha	1758-22G	1	piece
2CKA001731A1858	1764 NLI-22G Rocker with labelling field Switch/push button Single rocker ivory - alpha	1764 NLI-22G	1	piece
2CKA001710A2496	1766-22G Cover Plate TAE 1 gang ivory - alpha	1766-22G	1	piece
2CKA001710A2678	1769-22G Cover Plates (partly incl. Insert) AMP-ACO 1 gang ivory white - alpha	1769-22G	1	piece
2CKA001710A2397	1770-22G-101 Cover Plate Time switch Turn button Various symbols ivory - alpha	1770-22G-101	1	piece
2CKA001710A2405	1771-22G-101 Cover plate with legend Time switch Turn button 10 ... 120 Min ivory - alpha	1771-22G-101	1	piece
2CKA001751A2540	1781-22G Rocker with labelling field Switch/push button Single rocker ivory - alpha	1781-22G	1	piece
2CKA001751A2581	1785 JA-22G Rocker with legend Venetian blind Two-part rocker Symbol "arrows" ivory - alpha	1785 JA-22G	1	piece
2CKA001751A3140	1785 K-22G Rocker Switch/push button Two-part rocker ivory - alpha	1785 K-22G	1	piece
2CKA001751A2565	1785-22G Rocker Switch/push button Two-part rocker ivory - alpha	1785-22G	1	piece
2CKA001751A2722	1786 IO-22G Cover Plates (partly incl. Insert) Switch/push button Single rocker Characters 0 and 1 ivory - alpha	1786 IO-22G	1	piece
2CKA001751A3081	1786-22G-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint ivory - alpha	1786-22G-500	1	piece
2CKA001751A2508	1787-22G Rocker Switch/push button Single rocker ivory - alpha	1787-22G	1	piece
2CKA001751A2557	1788-22G Rocker Switch/push button Single rocker ivory - alpha	1788-22G	1	piece
2CKA001751A2573	1789 H-22G Rocker with legend Switch/push button Single rocker Heizung ivory - alpha	1789 H-22G	1	piece
2CKA001751A2524	1789 KI-22G Rocker with legend Switch/push button Single rocker Symbol "bell" ivory - alpha	1789 KI-22G	1	piece
2CKA001751A2516	1789 LI-22G Rocker with legend Switch/push button Single rocker Symbol "light" ivory - alpha	1789 LI-22G	1	piece
2CKA001751A2532	1789 TR-22G Rocker Switch/push button Single rocker ivory - alpha	1789 TR-22G	1	piece
2CKA001751A2490	1789-22G Rocker Switch/push button Single rocker ivory - alpha	1789-22G	1	piece
2CKA001710A3295	1792-22G-101 Cover plate with legend Hotel card Hotel card Card ivory - alpha	1792-22G-101	1	piece
2CKA001710A3686	1794 TA-22G Cover plate with legend for Thermostat Turn button ivory - alpha	1794 TA-22G	1	piece
2CKA001710A3534	1794-22G Cover plate with legend for Thermostat Turn button ivory - alpha	1794-22G	1	piece
2CKA001710A4000	1795 HK-22G Cover plate with legend for Thermostat Turn button ivory - alpha	1795 HK-22G	1	piece
2CKA001710A4032	1795 HKEA-22G Cover plate with legend for Thermostat Turn button 1 sliding switch ivory - alpha	1795 HKEA-22G	1	piece
2CKA001710A3713	1795 TA-22G Cover plate with legend for Thermostat Turn button 1 sliding switch ivory - alpha	1795 TA-22G	1	piece

2CKA001710A3559	1795-22G Cover plate with legend for Thermostat Turn button 1 sliding switch ivory - alpha	1795-22G	1	piece
2CKA001710A2645	1800-22G Cover plate with labelling field Modular Jack 2 gang ivory - alpha	1800-22G	1	piece
2CKA001710A2611	1803-02-22G Cover Plate UAE/IAE (ISDN) 2 gang ivory - alpha	1803-02-22G	1	piece
2CKA001710A2603	1803-22G Cover Plate UAE/IAE (ISDN) 2 gang ivory - alpha	1803-22G	1	piece
2CKA002011A6225	20 EUC-22G-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) ivory - alpha	20 EUC-22G- 500	1	piece
2CKA002013A5240	20 EUCKS-22G Socket insert Protective Contact (SCHUKO) Safety Shutter ivory white - alpha	20 EUCKS- 22G	1	piece
2CKA002018A1446	20 EUK-22G Socket insert Protective Contact (SCHUKO) with Hinged Lid ivory white - alpha	20 EUK-22G	1	piece
2CKA002017A0813	20 MUC-22G-500 Socket insert Earthing Pin ivory white - alpha	20 MUC-22G- 500	1	piece
2CKA002017A0828	20 MUCC-22G-500 Cover Plates (partly incl. Insert) Earthing Pin French norm NF ivory - alpha	20 MUCC-22G -500	1	piece
2CKA002017A0802	20 MUCKS-22G-500 Socket insert Earthing Pin Safety Shutter ivory white - alpha	20 MUCKS- 22G-500	1	piece
2CKA002113A0505	2300 UCRKS-22G-503 Cover Plates (partly incl. Insert) ivory - alpha	2300 UCRKS- 22G-503	1	piece
2CKA002011A3821	2310EUGL/VA-22G-11 Busch-Protector® Socket insert Protective Contact (SCHUKO) ivory white - alpha	2310EUGL/VA- 22G-11	1	piece
2CKA002099A0219	2399 UCKS-22G Cover Plates (partly incl. Insert) ivory - alpha	2399 UCKS- 22G	1	piece
2CKA001710A3115	2542 DR/01-22G Cover Plate Level switch Turn button Symbol "0-1-2-3" ivory - alpha	2542 DR/01- 22G	1	piece
2CKA001710A3426	2542 DR/02-22G Cover plate with legend Level switch Turn button Symbol "1-2-3" ivory - alpha	2542 DR/02- 22G	1	piece
2CKA001710A2512	2561-02-22G Cover Plate Modular Jack 2 gang ivory - alpha	2561-02-22G	1	piece
2CKA001710A2504	2561-22G Cover Plate Modular Jack 1 gang ivory - alpha	2561-22G	1	piece
2CKA006115A0478	6108/61-22G-500 Coverplate f. CE	6108/61-22G- 500	1	piece
2CKA006155A0055	6109/03-22G-500 Coverplate f. RTC	6109/03-22G- 500	1	piece
2CKA006430A0321	6430-22G-102 Control Element for Venetian blind Single push button ivory - alpha	6430-22G-102	1	piece
2CKA006430A0293	6435-22G Cover plate with legend for Time switch ivory - alpha	6435-22G	1	piece
2CKA006599A2795	6541-22G Cover Plate for Cooling Central cover plate ivory - alpha	6541-22G	1	piece
2CKA006599A2822	6543-22G-102 Control Element for Switch/dimmer Single push button with Neon lamp ivory - alpha	6543-22G-102	1	piece
2CKA006599A2892	6545-22G Control Element for Dimmer Two-part button with Neon lamp ivory - alpha	6545-22G	1	piece
2CKA001731A1930	1716-21 Cover Busch-Infolicht® bronze - alpha	1716-21	1	piece
2CKA001731A1933	1716-24G Cover Busch-Infolicht® studio white - alpha	1716-24G	1	piece
2CKA001731A1938	1716-260 Cover Busch-Infolicht® palladium - alpha	1716-260	1	piece
2CKA001731A1939	1716-266 Cover Busch-Infolicht® titanium - alpha	1716-266	1	piece
2CKA001753A1092	1740 DR-20 Cover plate with legend Venetian blind Turn button Symbol "arrows" and "0" platinum - alpha	1740 DR-20	1	piece
2CKA001753A1175	1740 DR-21 Cover plate with legend Venetian blind Turn button Symbol "arrows" and "0" bronze - alpha	1740 DR-21	1	piece
2CKA001753A7263	1740 DR-24G Cover plate with legend Venetian blind Turn button Symbol "arrows" and "0" studio white - alpha	1740 DR-24G	1	piece
2CKA001710A3302	1740 DR-260 Cover Plate Venetian blind Turn button Symbol "arrows" and "0" palladium - alpha	1740 DR-260	1	piece
2CKA001710A3328	1740 DR-266 Cover plate with legend Venetian blind Turn button Symbol "arrows" and "0" titanium - alpha	1740 DR-266	1	piece

2CKA001753A8279	1740 DRL-20 Cover Plates (partly incl. Insert) Level switch Turn button Symbol "2-1-3" platinum	1740 DRL-20	1	piece
2CKA001753A8287	1740 DRL-21 Cover Plates (partly incl. Insert) Level switch Turn button Symbol "2-1-3" bronze - alpha	1740 DRL-21	1	piece
2CKA001753A8246	1740 DRL-24G Cover Plates (partly incl. Insert) Level switch Turn button Symbol "2-1-3" studio white - alpha	1740 DRL-24G	1	piece
2CKA001710A3457	1740 DRL-260-503 Cover Plates (partly incl. Insert) Level switch Turn button Symbol "2-1-3" palladium - alpha	1740 DRL-260- 503	1	piece
2CKA001710A3459	1740 DRL-266-503 Cover Plates (partly incl. Insert) Level switch Turn button Symbol "2-1-3" titanium - alpha	1740 DRL-266- 503	1	piece
2CKA001753A1118	1742-20 Cover Plate Blind cap 1 gang with Mounting plate platinum - alpha	1742-20	1	piece
2CKA001753A1431	1742-21 Cover Plate Blind cap 1 gang with Mounting plate bronze - alpha	1742-21	1	piece
2CKA001753A7412	1742-24G Cover Plate Blind cap 1 gang with Mounting plate studio white - alpha	1742-24G	1	piece
2CKA001710A3309	1742-260 Cover Plate Blind cap 1 gang with Mounting plate palladium - alpha	1742-260	1	piece
2CKA001710A3335	1742-266 Cover Plate Blind cap 1 gang with Mounting plate titanium - alpha	1742-266	1	piece
2CKA001724A2822	1743-01-260-500 Cover Plate SAT 1 gang palladium - alpha	1743-01-260- 500	1	piece
2CKA001724A2825	1743-01-266-500 Cover Plate SAT 1 gang titanium - alpha	1743-01-266- 500	1	piece
2CKA001724A2747	1743-03-20-101 Cover Plate SAT 3 gang platinum - alpha	1743-03-20- 101	1	piece
2CKA001724A2748	1743-03-21-101 Cover Plate TV / Radio / SAT 3 gang bronze - alpha	1743-03-21- 101	1	piece
2CKA001724A1911	1743-03-24G Cover Plate SAT 3 gang studio white - alpha	1743-03-24G	1	piece
2CKA001724A2792	1743-03-260 Cover Plate SAT 3 gang palladium - alpha	1743-03-260	1	piece
2CKA001724A2797	1743-03-266 Cover Plate SAT 3 gang titanium - alpha	1743-03-266	1	piece
2CKA001753A1126	1743-20 Cover Plate SAT 2 gang platinum - alpha	1743-20	1	piece
2CKA001753A1449	1743-21 Cover Plate SAT 2 gang bronze - alpha	1743-21	1	piece
2CKA001753A7628	1743-24G Cover Plate SAT 2 gang studio white - alpha	1743-24G	1	piece
2CKA001724A2791	1743-260 Cover Plate SAT 2 gang palladium - alpha	1743-260	1	piece
2CKA001724A2796	1743-266 Cover Plate SAT 2 gang titanium - alpha	1743-266	1	piece
2CKA001753A8550	1746/10-20 Cover Plate Telecommunication inserts 50 x 50 mm platinum - alpha	1746/10-20	1	piece
2CKA001753A8568	1746/10-21 Cover Plate Telecommunication inserts 50 x 50 mm bronze - alpha	1746/10-21	1	piece
2CKA001710A2744	1746/10-24G Cover Plate Telecommunication inserts 50 x 50 mm studio white - alpha	1746/10-24G	1	piece
2CKA001710A3312	1746/10-260 Cover Plate Telecommunication inserts 50 x 50 mm palladium - alpha	1746/10-260	1	piece
2CKA001710A3338	1746/10-266 Cover Plate Telecommunication inserts 50 x 50 mm titanium - alpha	1746/10-266	1	piece
2CKA001753A1753	1746-20 FN Cover Plate Telecommunication inserts 1 gang platinum - alpha	1746-20 FN	1	piece
2CKA001753A5978	1746-20-101 Cover Plate Telecommunication inserts 50 x 50 mm 1 gang platinum - alpha	1746-20-101	1	piece
2CKA001753A1761	1746-21 FN Cover Plate Telecommunication inserts 1 gang bronze - alpha	1746-21 FN	1	piece
2CKA001753A5986	1746-21-101 Cover Plate Telecommunication inserts 50 x 50 mm 1 gang bronze - alpha	1746-21-101	1	piece
2CKA001753A7719	1746-24G FN Cover Plate Telecommunication inserts 1 gang studio white - alpha	1746-24G FN	1	piece
2CKA001753A7685	1746-24G-101 Cover Plate Telecommunication inserts 50 x 50 mm 1 gang studio white - alpha	1746-24G-101	1	piece
2CKA001710A3311	1746-260 FN Cover Plate Telecommunication inserts 1 gang palladium - alpha	1746-260 FN	1	piece

2CKA001710A3313	1746-260-101 Cover Plate Telecommunication inserts 50 x 50 mm 1 gang palladium - alpha	1746-260-101	1	piece
2CKA001710A3337	1746-266 FN Cover Plate Telecommunication inserts 1 gang titanium - alpha	1746-266 FN	1	piece
2CKA001710A3339	1746-266-101 Cover Plate Telecommunication inserts 50 x 50 mm 1 gang titanium - alpha	1746-266-101	1	piece
2CKA001753A1167	1748-20 Cover Plate Data connection 2 gang platinum - alpha	1748-20	1	piece
2CKA001753A1480	1748-21 Cover Plate Data connection 2 gang bronze - alpha	1748-21	1	piece
2CKA001753A7891	1748-24G Cover Plate Data connection 2 gang studio white - alpha	1748-24G	1	piece
2CKA001710A3323	1748-260 Cover Plate Data connection 2 gang palladium - alpha	1748-260	1	piece
2CKA001710A3349	1748-266 Cover Plate Data connection 2 gang titanium - alpha	1748-266	1	piece
2CKA001710A0904	1749-20 Cover Plate Cable outlet platinum - alpha	1749-20	1	piece
2CKA001710A0946	1749-21 Cover Plate Cable outlet bronze - alpha	1749-21	1	piece
2CKA001710A1209	1749-24G Cover Plate Cable outlet studio white - alpha	1749-24G	1	piece
2CKA001710A3316	1749-260 Cover Plate Cable outlet palladium - alpha	1749-260	1	piece
2CKA001710A3342	1749-266 Cover Plate Cable outlet titanium - alpha	1749-266	1	piece
2CKA001723A0113	1751-20 Cover Plate Loudspeaker 2 gang platinum - alpha	1751-20	1	piece
2CKA001723A0121	1751-21 Cover Plate Loudspeaker 2 gang bronze - alpha	1751-21	1	piece
2CKA001723A0204	1751-24G Cover Plate Loudspeaker 2 gang studio white - alpha	1751-24G	1	piece
2CKA001723A0245	1751-260 Cover Plate Loudspeaker 2 gang palladium - alpha	1751-260	1	piece
2CKA001723A0246	1751-266 Cover Plate Loudspeaker 2 gang titanium - alpha	1751-266	1	piece
2CKA001710A1522	1755 PZ-24G-101 Cover plate with legend Venetian blind Key Symbol "arrows" studio white - alpha	1755 PZ-24G-101	1	piece
2CKA001710A1597	1755 SLPZ-24G-101 Cover plate with legend Venetian blind Key Characters 0 and 1 studio white - alpha	1755 SLPZ-24G-101	1	piece
2CKA001753A1506	1756-20 Cover Plate Busch-Infolicht® platinum - alpha	1756-20	1	piece
2CKA001753A1522	1756-21 Cover Plate Busch-Infolicht® bronze - alpha	1756-21	1	piece
2CKA001753A7503	1756-24G Cover Plate Busch-Infolicht® studio white - alpha	1756-24G	1	piece
2CKA001710A3306	1756-260 Cover Plate Busch-Infolicht® palladium - alpha	1756-260	1	piece
2CKA001710A3332	1756-266 Cover Plate Busch-Infolicht® titanium - alpha	1756-266	1	piece
2CKA001724A1010	1758-20 Cover plate with labelling field For data connection housing 2 gang platinum - alpha	1758-20	1	piece
2CKA001724A1028	1758-21 Cover plate with labelling field For data connection housing 2 gang bronze - alpha	1758-21	1	piece
2CKA001724A2067	1758-24G Cover plate with labelling field For data connection housing 2 gang studio white - alpha	1758-24G	1	piece
2CKA001724A2793	1758-260 Cover Plate For data connection housing 2 gang palladium	1758-260	1	piece
2CKA001724A2798	1758-266 Cover plate with labelling field For data connection housing 2 gang titanium - alpha	1758-266	1	piece
2CKA001731A1569	1764 NLI-24G Rocker with labelling field Switch/push button Single rocker studio white - alpha	1764 NLI-24G	1	piece
2CKA001753A2629	1766-20 Cover Plate TAE 1 gang platinum - alpha	1766-20	1	piece
2CKA001753A2637	1766-21 Cover Plate TAE 1 gang bronze - alpha	1766-21	1	piece
2CKA001753A7743	1766-24G Cover Plate TAE 1 gang studio white - alpha	1766-24G	1	piece
2CKA001710A3310	1766-260 Cover Plate TAE 1 gang palladium - alpha	1766-260	1	piece

2CKA001710A3336	1766-266 Cover Plate TAE 1 gang titanium - alpha	1766-266	1	piece
2CKA001753A8832	1769-20 Cover Plates (partly incl. Insert) AMP-ACO 1 gang platinum - alpha	1769-20	1	piece
2CKA001753A8840	1769-21 Cover Plates (partly incl. Insert) AMP-ACO 1 gang bronze - alpha	1769-21	1	piece
2CKA001710A2736	1769-24G Cover plate with labelling field AMP-ACO 1 gang studio white - alpha	1769-24G	1	piece
2CKA001710A3317	1769-260 Cover Plates (partly incl. Insert) AMP-ACO 1 gang palladium - alpha	1769-260	1	piece
2CKA001710A3343	1769-266 Cover Plates (partly incl. Insert) AMP-ACO 1 gang titanium - alpha	1769-266	1	piece
2CKA001753A6075	1770-20-101 Cover plate with legend Time switch Turn button 1 ... 15 Min platinum - alpha	1770-20-101	1	piece
2CKA001753A6083	1770-21-101 Cover plate with legend Time switch Turn button 1 ... 15 Min bronze - alpha	1770-21-101	1	piece
2CKA001753A7446	1770-24G-101 Cover plate with legend Time switch Turn button 1 ... 15 Min studio white - alpha	1770-24G-101	1	piece
2CKA001753A6224	1771-20-101 Cover plate with legend Time switch Turn button 10 ... 120 Min platinum - alpha	1771-20-101	1	piece
2CKA001753A6232	1771-21-101 Cover plate with legend Time switch Turn button 10 ... 120 Min bronze - alpha	1771-21-101	1	piece
2CKA001753A7479	1771-24G-101 Cover plate with legend Time switch Turn button 10 ... 120 Min studio white - alpha	1771-24G-101	1	piece
2CKA001753A7354	1775-24G-101 Accessories	1775-24G-101	1	piece
2CKA001751A1666	1781-20 Rocker with labelling field Switch/push button Single rocker platinum - alpha	1781-20	1	piece
2CKA001751A1757	1781-21 Rocker with labelling field Switch/push button Single rocker bronze - alpha	1781-21	1	piece
2CKA001751A2292	1781-24G Rocker with labelling field Switch/push button Single rocker studio white - alpha	1781-24G	1	piece
2CKA001751A2822	1781-260 Rocker Switch/push button Single rocker palladium - alpha	1781-260	1	piece
2CKA001751A2833	1781-266 Rocker with labelling field Switch/push button Single rocker titanium - alpha	1781-266	1	piece
2CKA001751A3113	1785 JA/02-20 Rocker with legend Venetian blind Two-part rocker Symbol "arrows" platinum	1785 JA/02-20	1	piece
2CKA001751A3111	1785 JA/02-21 Rocker with legend Venetian blind Two-part rocker Symbol "arrows" bronze	1785 JA/02-21	1	piece
2CKA001751A3107	1785 JA/02-24G Rocker with legend Venetian blind Two-part rocker Symbol "arrows" studio white	1785 JA/02-24G	1	piece
2CKA001751A1823	1785 JA-20 Rocker with legend Venetian blind Two-part rocker Symbol "arrows" platinum - alpha	1785 JA-20	1	piece
2CKA001751A1831	1785 JA-21 Rocker with legend Venetian blind Two-part rocker Symbol "arrows" bronze - alpha	1785 JA-21	1	piece
2CKA001751A2128	1785 JA-24G Rocker with legend Venetian blind Two-part rocker Symbol "arrows" studio white - alpha	1785 JA-24G	1	piece
2CKA001751A2831	1785 JA-260 Rocker Venetian blind Two-part rocker palladium - alpha	1785 JA-260	1	piece
2CKA001751A2842	1785 JA-266 Rocker with legend Venetian blind Two-part rocker Symbol "arrows" titanium - alpha	1785 JA-266	1	piece
2CKA001751A3138	1785 K-20 Rocker Switch/push button Two-part rocker platinum - alpha	1785 K-20	1	piece
2CKA001751A3139	1785 K-21 Rocker Switch/push button Two-part rocker bronze - alpha	1785 K-21	1	piece
2CKA001751A3142	1785 K-24G Rocker Switch/push button Two-part rocker studio white - alpha	1785 K-24G	1	piece
2CKA001751A3143	1785 K-260 Rocker Switch/push button Two-part rocker palladium - alpha	1785 K-260	1	piece
2CKA001751A3144	1785 K-266 Rocker Switch/push button Two-part rocker titanium - alpha	1785 K-266	1	piece
2CKA001751A1682	1785-20 Rocker Switch/push button Two-part rocker platinum - alpha	1785-20	1	piece
2CKA001751A1773	1785-21 Rocker Switch/push button Two-part rocker bronze - alpha	1785-21	1	piece



2CKA001751A2706	1785-21-101 Cover Plates (partly incl. Insert) Switch/push button Two-part rocker Without imprint bronze - alpha	1785-21-101	1	piece
2CKA001751A2110	1785-24G Rocker Switch/push button Two-part rocker studio white - alpha	1785-24G	1	piece
2CKA001751A2827	1785-260 Rocker Switch/push button Two-part rocker palladium - alpha	1785-260	1	piece
2CKA001751A3082	1785-260-500 Cover Plates (partly incl. Insert) Switch/push button Two-part rocker Without imprint palladium - alpha	1785-260-500	1	piece
2CKA001751A2838	1785-266 Rocker Switch/push button Two-part rocker titanium - alpha	1785-266	1	piece
2CKA001751A3112	1786 JA/02-20 Rocker Venetian blind Single rocker platinum - alpha	1786 JA/02-20	1	piece
2CKA001751A3110	1786 JA/02-21 Rocker with legend Switch/push button Symbol "arrows" bronze	1786 JA/02-21	1	piece
2CKA001751A3106	1786 JA/02-24G Rocker Venetian blind Single rocker studio white - alpha	1786 JA/02- 24G	1	piece
2CKA001751A3114	1786 JA/02-260 Rocker with legend Switch/push button Symbol "arrows" palladium	1786 JA/02- 260	1	piece
2CKA001751A3090	1786-20-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint platinum - alpha	1786-20-500	1	piece
2CKA001751A3086	1786-21-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint bronze - alpha	1786-21-500	1	piece
2CKA001751A3078	1786-24G-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint studio white	1786-24G-500	1	piece
2CKA001751A3080	1786-260-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint palladium - alpha	1786-260-500	1	piece
2CKA001751A3085	1786-266-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint titanium - alpha	1786-266-500	1	piece
2CKA001751A2045	1787-20 Rocker Switch/push button Single rocker platinum - alpha	1787-20	1	piece
2CKA001751A2052	1787-21 Rocker Switch/push button Single rocker bronze - alpha	1787-21	1	piece
2CKA001751A2177	1787-24G Rocker Switch/push button Single rocker studio white - alpha	1787-24G	1	piece
2CKA001751A2824	1787-260 Rocker Switch/push button Single rocker palladium - alpha	1787-260	1	piece
2CKA001751A2835	1787-266 Rocker Switch/push button Single rocker titanium - alpha	1787-266	1	piece
2CKA001751A1674	1788-20 Rocker Switch/push button Single rocker platinum - alpha	1788-20	1	piece
2CKA001751A1765	1788-21 Rocker Switch/push button Single rocker bronze - alpha	1788-21	1	piece
2CKA001751A2326	1788-24G Rocker Switch/push button Single rocker studio white - alpha	1788-24G	1	piece
2CKA001751A2823	1788-260 Rocker Switch/push button Single rocker palladium - alpha	1788-260	1	piece
2CKA001751A2834	1788-266 Rocker Switch/push button Single rocker titanium - alpha	1788-266	1	piece
2CKA001751A1690	1789 H-20 Rocker with legend Switch/push button Single rocker Heizung platinum - alpha	1789 H-20	1	piece
2CKA001751A1781	1789 H-21 Rocker with legend Switch/push button Single rocker Heizung bronze - alpha	1789 H-21	1	piece
2CKA001751A2375	1789 H-24G Rocker with legend Switch/push button Single rocker Heizung studio white - alpha	1789 H-24G	1	piece
2CKA001751A2826	1789 H-260 Rocker with legend Switch/push button Single rocker Heizung palladium - alpha	1789 H-260	1	piece
2CKA001751A2837	1789 H-266 Rocker with legend Switch/push button Single rocker Heizung titanium - alpha	1789 H-266	1	piece
2CKA001751A1641	1789 KI-20 Rocker Switch/push button Single rocker platinum - alpha	1789 KI-20	1	piece
2CKA001751A1732	1789 KI-21 Rocker Switch/push button Single rocker bronze - alpha	1789 KI-21	1	piece



2CKA001751A2235	1789 KI-24G Rocker with legend Switch/push button Single rocker Symbol "bell" studio white - alpha	1789 KI-24G	1	piece
2CKA001751A2829	1789 KI-260 Rocker with legend Switch/push button Single rocker Symbol "bell" palladium - alpha	1789 KI-260	1	piece
2CKA001751A2840	1789 KI-266 Rocker with legend Switch/push button Single rocker Symbol "bell" titanium - alpha	1789 KI-266	1	piece
2CKA001751A1633	1789 LI-20 Rocker with legend Switch/push button Single rocker Symbol "light" platinum - alpha	1789 LI-20	1	piece
2CKA001751A1724	1789 LI-21 Rocker with legend Switch/push button Single rocker Symbol "light" bronze - alpha	1789 LI-21	1	piece
2CKA001751A2201	1789 LI-24G Rocker with legend Switch/push button Single rocker Symbol "light" studio white - alpha	1789 LI-24G	1	piece
2CKA001751A2828	1789 LI-260 Rocker with legend Switch/push button Single rocker Symbol "light" palladium - alpha	1789 LI-260	1	piece
2CKA001751A2839	1789 LI-266 Rocker with legend Switch/push button Single rocker Symbol "light" titanium - alpha	1789 LI-266	1	piece
2CKA001751A1658	1789 TR-20 Rocker with legend Switch/push button Single rocker Symbol "key/door" platinum	1789 TR-20	1	piece
2CKA001751A1740	1789 TR-21 Rocker Switch/push button Single rocker bronze - alpha	1789 TR-21	1	piece
2CKA001751A2268	1789 TR-24G Rocker Switch/push button Single rocker studio white - alpha	1789 TR-24G	1	piece
2CKA001751A2830	1789 TR-260 Rocker Switch/push button Single rocker palladium - alpha	1789 TR-260	1	piece
2CKA001751A2841	1789 TR-266 Rocker Switch/push button Single rocker titanium - alpha	1789 TR-266	1	piece
2CKA001751A1625	1789-20 Rocker Switch/push button Single rocker platinum - alpha	1789-20	1	piece
2CKA001751A1716	1789-21 Rocker Switch/push button Single rocker bronze - alpha	1789-21	1	piece
2CKA001751A2102	1789-24G Rocker Switch/push button Single rocker studio white - alpha	1789-24G	1	piece
2CKA001751A2825	1789-260 Rocker Switch/push button Single rocker palladium - alpha	1789-260	1	piece
2CKA001751A2836	1789-266 Rocker Switch/push button Single rocker titanium - alpha	1789-266	1	piece
2CKA001710A3293	1792-20-101 Cover plate with legend Switch/push button Hotel card Hotel card Card platinum - alpha	1792-20-101	1	piece
2CKA001710A3294	1792-21-101 Cover plate with legend Hotel card Hotel card Card bronze - alpha	1792-21-101	1	piece
2CKA001710A3297	1792-24G-101 Cover plate with legend Hotel card Hotel card Card studio white - alpha	1792-24G-101	1	piece
2CKA001710A3305	1792-260-101 Cover plate with legend Hotel card Hotel card Card palladium - alpha	1792-260-101	1	piece
2CKA001710A3331	1792-266-101 Cover plate with legend Hotel card Hotel card Card titanium - alpha	1792-266-101	1	piece
2CKA001710A3684	1794 TA-20 Cover plate with legend for Thermostat Turn button platinum - alpha	1794 TA-20	1	piece
2CKA001710A3685	1794 TA-21 Cover plate with legend for Thermostat Turn button bronze - alpha	1794 TA-21	1	piece
2CKA001710A3688	1794 TA-24G Cover plate with legend for Thermostat Turn button studio white - alpha	1794 TA-24G	1	piece
2CKA001710A3693	1794 TA-260 Cover plate with legend for Thermostat Turn button palladium - alpha	1794 TA-260	1	piece
2CKA001710A3694	1794 TA-266 Cover plate with legend for Thermostat Turn button titanium - alpha	1794 TA-266	1	piece
2CKA001710A3532	1794-20 Cover plate with legend for Thermostat Turn button platinum - alpha	1794-20	1	piece
2CKA001710A3533	1794-21 Cover plate with legend for Thermostat Turn button bronze - alpha	1794-21	1	piece
2CKA001710A3536	1794-24G Cover plate with legend for Thermostat Turn button studio white - alpha	1794-24G	1	piece
2CKA001710A3541	1794-260 Cover plate with legend for Thermostat Turn button palladium - alpha	1794-260	1	piece

2CKA001710A3542	1794-266 Cover plate with legend for Thermostat Turn button titanium - alpha	1794-266	1	piece
2CKA001710A3998	1795 HK-20 Cover plate with legend for Thermostat Turn button platinum - alpha	1795 HK-20	1	piece
2CKA001710A3999	1795 HK-21 Cover plate with legend for Thermostat Turn button bronze - alpha	1795 HK-21	1	piece
2CKA001710A4002	1795 HK-24G Cover plate with legend for Thermostat Turn button studio white - alpha	1795 HK-24G	1	piece
2CKA001710A4003	1795 HK-260 Cover plate with legend for Thermostat Turn button palladium - alpha	1795 HK-260	1	piece
2CKA001710A4004	1795 HK-266 Cover plate with legend for Thermostat Turn button titanium - alpha	1795 HK-266	1	piece
2CKA001710A4030	1795 HKEA-20 Cover plate with legend for Thermostat Turn button 1 sliding switch platinum - alpha	1795 HKEA-20	1	piece
2CKA001710A4031	1795 HKEA-21 Cover plate with legend for Thermostat Turn button 1 sliding switch bronze - alpha	1795 HKEA-21	1	piece
2CKA001710A4034	1795 HKEA-24G Cover plate with legend for Thermostat Turn button 1 sliding switch studio white - alpha	1795 HKEA-24G	1	piece
2CKA001710A4035	1795 HKEA-260 Cover plate with legend for Thermostat Turn button 1 sliding switch palladium - alpha	1795 HKEA-260	1	piece
2CKA001710A4036	1795 HKEA-266 Cover plate with legend for Thermostat Turn button 1 sliding switch titanium - alpha	1795 HKEA-266	1	piece
2CKA001710A3711	1795 TA-20 Cover plate with legend for Thermostat Turn button 1 sliding switch platinum - alpha	1795 TA-20	1	piece
2CKA001710A3712	1795 TA-21 Cover plate with legend for Thermostat Turn button 1 sliding switch bronze - alpha	1795 TA-21	1	piece
2CKA001710A3715	1795 TA-24G Cover plate with legend for Thermostat Turn button 1 sliding switch studio white - alpha	1795 TA-24G	1	piece
2CKA001710A3720	1795 TA-260 Cover plate with legend for Thermostat Turn button 1 sliding switch palladium - alpha	1795 TA-260	1	piece
2CKA001710A3721	1795 TA-266 Cover plate with legend for Thermostat Turn button 1 sliding switch titanium - alpha	1795 TA-266	1	piece
2CKA001710A3557	1795-20 Cover plate with legend for Thermostat Turn button 1 sliding switch platinum - alpha	1795-20	1	piece
2CKA001710A3558	1795-21 Cover plate with legend for Thermostat Turn button 1 sliding switch bronze - alpha	1795-21	1	piece
2CKA001710A3561	1795-24G Cover plate with legend for Thermostat Turn button 1 sliding switch studio white - alpha	1795-24G	1	piece
2CKA001710A3566	1795-260 Cover plate with legend for Thermostat Turn button 1 sliding switch palladium - alpha	1795-260	1	piece
2CKA001710A3567	1795-266 Cover plate with legend for Thermostat Turn button 1 sliding switch titanium - alpha	1795-266	1	piece
2CKA001753A9178	1800-20 Cover plate with labelling field Modular Jack 2 gang platinum - alpha	1800-20	1	piece
2CKA001753A9186	1800-21 Cover plate with labelling field Modular Jack 2 gang bronze - alpha	1800-21	1	piece
2CKA001710A2710	1800-24G Cover plate with labelling field Modular Jack 2 gang studio white - alpha	1800-24G	1	piece
2CKA001710A3318	1800-260 Cover Plate Modular Jack 2 gang palladium - alpha	1800-260	1	piece
2CKA001710A3344	1800-266 Cover plate with labelling field Modular Jack 2 gang titanium - alpha	1800-266	1	piece
2CKA001753A8485	1803-02-20 Cover Plate UAE/IAE (ISDN) 2 gang platinum - alpha	1803-02-20	1	piece
2CKA001753A8493	1803-02-21 Cover Plate UAE/IAE (ISDN) 2 gang bronze - alpha	1803-02-21	1	piece
2CKA001710A2033	1803-02-24G Cover Plate UAE/IAE (ISDN) 2 gang studio white - alpha	1803-02-24G	1	piece
2CKA001710A3321	1803-02-260 Cover Plate UAE/IAE (ISDN) 2 gang palladium - alpha	1803-02-260	1	piece
2CKA001710A3347	1803-02-266 Cover Plate UAE/IAE (ISDN) 2 gang titanium - alpha	1803-02-266	1	piece

2CKA001753A8410	1803-20 Cover Plate UAE/IAE (ISDN) 1 gang platinum - alpha	1803-20	1	piece
2CKA001753A8428	1803-21 Cover Plate UAE/IAE (ISDN) 1 gang bronze - alpha	1803-21	1	piece
2CKA001710A2025	1803-24G Cover Plate UAE/IAE (ISDN) 1 gang studio white - alpha	1803-24G	1	piece
2CKA001710A3322	1803-260 Cover Plate UAE/IAE (ISDN) 1 gang palladium - alpha	1803-260	1	piece
2CKA001710A3348	1803-266 Cover Plate UAE/IAE (ISDN) 1 gang titanium - alpha	1803-266	1	piece
2CKA002011A6222	20 EUC-20-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) platinum - alpha	20 EUC-20-500	1	piece
2CKA002011A6221	20 EUC-21-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) bronze - alpha	20 EUC-21-500	1	piece
2CKA002011A6223	20 EUC-24G-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) studio white - alpha	20 EUC-24G-500	1	piece
2CKA002011A6229	20 EUC-260-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) palladium - alpha	20 EUC-260-500	1	piece
2CKA002011A6226	20 EUC-266-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) titanium - alpha	20 EUC-266-500	1	piece
2CKA002013A4458	20 EUCKS-20 Socket insert Protective Contact (SCHUKO) Safety Shutter platinum - alpha	20 EUCKS-20	1	piece
2CKA002013A4466	20 EUCKS-21 Socket insert Protective Contact (SCHUKO) Safety Shutter bronze - alpha	20 EUCKS-21	1	piece
2CKA002013A5377	20 EUCKS-24G-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) studio white - alpha	20 EUCKS-24G-500	1	piece
2CKA002013A5252	20 EUCKS-260 Socket insert Protective Contact (SCHUKO) Safety Shutter palladium - alpha	20 EUCKS-260	1	piece
2CKA002013A5253	20 EUCKS-266 Socket insert Protective Contact (SCHUKO) Safety Shutter titanium - alpha	20 EUCKS-266	1	piece
2CKA002018A0695	20 EUK-20 Socket insert Protective Contact (SCHUKO) with Hinged Lid platinum - alpha	20 EUK-20	1	piece
2CKA002018A0703	20 EUK-21 Socket insert Protective Contact (SCHUKO) with Hinged Lid bronze - alpha	20 EUK-21	1	piece
2CKA002018A1040	20 EUK-24G Socket insert Protective Contact (SCHUKO) with Hinged Lid studio white - alpha	20 EUK-24G	1	piece
2CKA002018A1464	20 EUK-260 Socket insert Protective Contact (SCHUKO) with Hinged Lid palladium - alpha	20 EUK-260	1	piece
2CKA002018A1466	20 EUK-266 Socket insert Protective Contact (SCHUKO) with Hinged Lid titanium - alpha	20 EUK-266	1	piece
2CKA002017A0808	20 MUC-20-500 Socket insert Earthing Pin platinum - alpha	20 MUC-20-500	1	piece
2CKA002017A0811	20 MUC-21-500 Socket insert Earthing Pin bronze - alpha	20 MUC-21-500	1	piece
2CKA002017A0815	20 MUC-24G-500 Cover Plates (partly incl. Insert) French norm NF studio white - alpha	20 MUC-24G-500	1	piece
2CKA002017A0817	20 MUC-260-500 Socket insert Earthing Pin palladium - alpha	20 MUC-260-500	1	piece
2CKA002017A0818	20 MUC-266-500 Socket insert Earthing Pin titanium - alpha	20 MUC-266-500	1	piece
2CKA002017A0825	20 MUCC-20-500 Socket insert Earthing Pin platinum - alpha	20 MUCC-20-500	1	piece
2CKA002017A0829	20 MUCC-24G-500 Socket insert Earthing Pin studio white - alpha	20 MUCC-24G-500	1	piece
2CKA002017A0832	20 MUCKS-20-500 Socket insert Earthing Pin Safety Shutter platinum - alpha	20 MUCKS-20-500	1	piece
2CKA002017A0835	20 MUCKS-21-500 Cover Plates (partly incl. Insert) French norm NF bronze - alpha	20 MUCKS-21-500	1	piece
2CKA002017A0803	20 MUCKS-24G-500 Cover Plates (partly incl. Insert) French norm NF studio white - alpha	20 MUCKS-24G-500	1	piece
2CKA002017A0804	20 MUCKS-260-500 Socket insert Earthing Pin Safety Shutter palladium - alpha	20 MUCKS-260-500	1	piece
2CKA002017A0805	20 MUCKS-266-500 Socket insert Earthing Pin Safety Shutter titanium - alpha	20 MUCKS-266-500	1	piece
2CKA002111A0623	2300 UCRKS-24G-503 Cover Plates (partly incl. Insert) studio white - alpha	2300 UCRKS-24G-503	1	piece
2CKA002113A0508	2300 UCRKS-260-503 Cover Plates (partly incl. Insert) palladium - alpha	2300 UCRKS-260-503	1	piece

2CKA002113A0509	2300 UCRKS-266-503 Cover Plates (partly incl. Insert) titanium - alpha	2300 UCRKS-266-503	1	piece
2CKA002113A0033	2300-01 UC-20-500 Cover Plates (partly incl. Insert) platinum - alpha	2300-01 UC-20-500	1	piece
2CKA002113A0041	2300-01 UC-21-500 Cover Plates (partly incl. Insert) bronze - alpha	2300-01 UC-21-500	1	piece
2CKA002011A3819	2310 EUGL/VA-20-11 Busch-Protector® Socket insert Protective Contact (SCHUKO) platinum - alpha	2310 EUGL/VA-20-11	1	piece
2CKA002011A3820	2310 EUGL/VA-21-11 Busch-Protector® Socket insert Protective Contact (SCHUKO) bronze - alpha	2310 EUGL/VA-21-11	1	piece
2CKA002011A3823	2310 EUGL/VA-24G-11 Busch-Protector® Socket insert Protective Contact (SCHUKO) studio white - alpha	2310 EUGL/VA-24G-11	1	piece
2CKA002011A3828	2310 EUGL/VA-260-11 Busch-Protector® Socket insert Protective Contact (SCHUKO) palladium - alpha	2310 EUGL/VA-260-11	1	piece
2CKA002011A3829	2310 EUGL/VA-266-11 Busch-Protector® Socket insert Protective Contact (SCHUKO) titanium - alpha	2310 EUGL/VA-266-11	1	piece
2CKA002099A0225	2399 UCKS-20 Cover Plates (partly incl. Insert) platinum - alpha	2399 UCKS-20	1	piece
2CKA002099A0226	2399 UCKS-21 Cover Plates (partly incl. Insert) bronze - alpha	2399 UCKS-21	1	piece
2CKA002099A0220	2399 UCKS-24G Cover Plates (partly incl. Insert) studio white - alpha	2399 UCKS-24G	1	piece
2CKA002099A0223	2399 UCKS-260 Cover Plates (partly incl. Insert) palladium - alpha	2399 UCKS-260	1	piece
2CKA002099A0224	2399 UCKS-266 Cover Plates (partly incl. Insert) titanium - alpha	2399 UCKS-266	1	piece
2CKA001710A3113	2542 DR/01-20 Cover plate with legend Level switch Turn button Symbol "0-1-2-3" platinum - alpha	2542 DR/01-20	1	piece
2CKA001710A3114	2542 DR/01-21 Cover plate with legend Level switch Turn button Symbol "0-1-2-3" bronze - alpha	2542 DR/01-21	1	piece
2CKA001710A3117	2542 DR/01-24G Cover plate with legend Level switch Turn button Symbol "0-1-2-3" studio white - alpha	2542 DR/01-24G	1	piece
2CKA001710A3464	2542 DR/01-260 Cover plate with legend Level switch Turn button Symbol "0-1-2-3" palladium - alpha	2542 DR/01-260	1	piece
2CKA001710A3466	2542 DR/01-266 Cover plate with legend Level switch Turn button Symbol "0-1-2-3" titanium - alpha	2542 DR/01-266	1	piece
2CKA001710A3424	2542 DR/02-20 Cover plate with legend Level switch Turn button Symbol "1-2-3" platinum - alpha	2542 DR/02-20	1	piece
2CKA001710A3425	2542 DR/02-21 Cover plate with legend Level switch Turn button Symbol "1-2-3" bronze - alpha	2542 DR/02-21	1	piece
2CKA001710A3428	2542 DR/02-24G Cover plate with legend Level switch Turn button Symbol "1-2-3" studio white - alpha	2542 DR/02-24G	1	piece
2CKA001710A3465	2542 DR/02-260 Cover plate with legend Level switch Turn button Symbol "1-2-3" palladium - alpha	2542 DR/02-260	1	piece
2CKA001710A3467	2542 DR/02-266 Cover plate with legend Level switch Turn button Symbol "1-2-3" titanium - alpha	2542 DR/02-266	1	piece
2CKA001753A4047	2561-02-20 Cover Plate Modular Jack 2 gang platinum - alpha	2561-02-20	1	piece
2CKA001753A4054	2561-02-21 Cover Plate Modular Jack 2 gang bronze - alpha	2561-02-21	1	piece
2CKA001753A7800	2561-02-24G Cover Plate Modular Jack 2 gang studio white - alpha	2561-02-24G	1	piece
2CKA001710A3315	2561-02-260 Cover Plate Modular Jack 2 gang palladium - alpha	2561-02-260	1	piece
2CKA001710A3341	2561-02-266 Cover Plate Modular Jack 2 gang titanium - alpha	2561-02-266	1	piece
2CKA001753A3916	2561-20 Cover Plate Modular Jack 1 gang platinum - alpha	2561-20	1	piece

2CKA001753A3924	2561-21 Cover Plate Modular Jack 1 gang bronze - alpha	2561-21	1	piece
2CKA001753A7776	2561-24G Cover Plate Modular Jack 1 gang studio white - alpha	2561-24G	1	piece
2CKA001710A3314	2561-260 Cover Plate Modular Jack 1 gang palladium - alpha	2561-260	1	piece
2CKA001710A3340	2561-266 Cover Plate Modular Jack 1 gang titanium - alpha	2561-266	1	piece
2CKA002122A0028	3016 EUC-24G Socket insert NEMA studio white	3016 EUC-24G	1	piece
2CKA006115A0476	6108/61-20-500 Coverplate f. CE	6108/61-20- 500	1	piece
2CKA006115A0477	6108/61-21-500 Coverplate f. CE	6108/61-21- 500	1	piece
2CKA006115A0480	6108/61-24G-500 Coverplate f. CE	6108/61-24G- 500	1	piece
2CKA006115A0481	6108/61-260-500 Coverplate f. CE	6108/61-260- 500	1	piece
2CKA006115A0482	6108/61-266-500 Coverplate f. CE	6108/61-266- 500	1	piece
2CKA006155A0053	6109/03-20-500 Coverplate f. RTC	6109/03-20- 500	1	piece
2CKA006155A0054	6109/03-21-500 Coverplate f. RTC	6109/03-21- 500	1	piece
2CKA006155A0057	6109/03-24G-500 Coverplate f. RTC	6109/03-24G- 500	1	piece
2CKA006155A0058	6109/03-260-500 Coverplate f. RTC	6109/03-260- 500	1	piece
2CKA006155A0059	6109/03-266-500 Coverplate f. RTC	6109/03-266- 500	1	piece
2CKA006430A0319	6430-20-102 Control Element for Venetian blind Single push button platinum - alpha	6430-20-102	1	piece
2CKA006430A0320	6430-21-102 Control Element for Venetian blind Single push button bronze - alpha	6430-21-102	1	piece
2CKA006430A0323	6430-24G-102 Control Element for Venetian blind Single push button studio white - alpha	6430-24G-102	1	piece
2CKA006430A0317	6430-260-102 Control Element for Venetian blind Single push button palladium - alpha	6430-260-102	1	piece
2CKA006430A0318	6430-266-102 Control Element for Venetian blind Single push button titanium - alpha	6430-266-102	1	piece
2CKA006430A0291	6435-20 Cover plate with legend for Time switch platinum - alpha	6435-20	1	piece
2CKA006430A0292	6435-21 Cover plate with legend for Time switch bronze - alpha	6435-21	1	piece
2CKA006430A0295	6435-24G Cover plate with legend for Time switch studio white - alpha	6435-24G	1	piece
2CKA006430A0289	6435-260 Cover plate with legend for Time switch palladium - alpha	6435-260	1	piece
2CKA006430A0290	6435-266 Cover plate with legend for Time switch titanium - alpha	6435-266	1	piece
2CKA006599A1458	6540-20 Cover Plate for Dimmer Turn button platinum - alpha	6540-20	1	piece
2CKA006599A1490	6540-21 Cover Plate for Dimmer Turn button bronze - alpha	6540-21	1	piece
2CKA006599A2324	6540-24G Cover Plate for Dimmer Turn button studio white - alpha	6540-24G	1	piece
2CKA006599A2852	6540-260 Cover Plate for Dimmer Turn button palladium - alpha	6540-260	1	piece
2CKA006599A2855	6540-266 Cover Plate for Dimmer Turn button titanium - alpha	6540-266	1	piece
2CKA006599A1466	6541-20 Cover Plate for Cooling Central cover plate platinum - alpha	6541-20	1	piece
2CKA006599A1524	6541-21 Cover Plate for Cooling Central cover plate bronze - alpha	6541-21	1	piece
2CKA006599A2332	6541-24G Cover Plate for Cooling Central cover plate studio white - alpha	6541-24G	1	piece
2CKA006599A2853	6541-260 Cover Plate for Cooling Central cover plate palladium - alpha	6541-260	1	piece
2CKA006599A2856	6541-266 Cover Plate for Cooling Central cover plate titanium - alpha	6541-266	1	piece

2CKA006599A2820	6543-20-102 Control Element for Switch/dimmer Single push button with Neon lamp platinum - alpha	6543-20-102	1	piece
2CKA006599A2821	6543-21-102 Control Element for Switch/dimmer Single push button with Neon lamp bronze - alpha	6543-21-102	1	piece
2CKA006599A2824	6543-24G-102 Control Element for Switch/dimmer Single push button with Neon lamp studio white - alpha	6543-24G-102	1	piece
2CKA006599A2869	6543-260-102 Control Element for Switch/dimmer Single push button with Neon lamp palladium - alpha	6543-260-102	1	piece
2CKA006599A2870	6543-266-102 Control Element for Switch/dimmer Single push button with Neon lamp titanium - alpha	6543-266-102	1	piece
2CKA006599A2890	6545-20 Control Element for Dimmer Two-part button with Neon lamp platinum - alpha	6545-20	1	piece
2CKA006599A2891	6545-21 Control Element for Dimmer Two-part button with Neon lamp bronze - alpha	6545-21	1	piece
2CKA006599A2894	6545-24G Control Element for Dimmer Two-part button with Neon lamp studio white - alpha	6545-24G	1	piece
2CKA006599A2899	6545-260 Control Element for Dimmer Two-part button with Neon lamp palladium - alpha	6545-260	1	piece
2CKA006599A2900	6545-266 Control Element for Dimmer Two-part button with Neon lamp titanium - alpha	6545-266	1	piece
2CKA008200A0093	8253-20 Cover Plate Loudspeaker platinum - alpha	8253-20	1	piece
2CKA008200A0094	8253-21 Cover Plate Loudspeaker bronze - alpha	8253-21	1	piece

---

## Catégories

---

Produits basse tension → Wiring Accessories - Light Switch Ranges → Frames

